



MonsterShop

SUP REPAIR KIT

REPAIR PROCEDURES

Small Leaks & Punctures

The repair of a small leak or puncture less than 0.5" (12.7mm) can be fixed with a round patch that is a minimum of 3" (76.2mm) in diameter.

1. Make sure that the paddle board surface is clean and dry before application.
2. Apply three even coats of glue to the surface of the paddle board and patch, waiting 5 minutes between each coat. After the third coat, wait 10-15 minutes before applying the patch to the paddle board.
3. Wait 24 hours before re-inflating and using the paddle board.

Valve Installation

Use the valve wrench included to loosen and tighten the valve where necessary. In order to do this, you will need to get a grip of the nut on the inside of your paddleboard by reaching round the underside of your paddle board, opposite of the valve.

If the valve needs replacing, please contact our friendly Customer Support Team who will be happy to help.