

Wheel Assembly

Thank you for purchasing the MaxBlast Industrial Vacuum.

Please follow these simple instructions to assemble the wheels onto the pedestal.



Step 1:

Push the two front castor wheels into the corresponding pedestal holes. Push with a firm grip and a bit of force to ensure the wheels are attached properly.



Step 2:

Line up the rear wheels with the mounting holes and cover with the pressure plates.



Step 3:

Fasten the rear wheels in place using screws.

For any issues please contact our Support team on 01347 878887.