

CPK50 Chicken Plucking Machine



Try Monster - Buy Monster - Be Monster

Specification

Product Description

KuKoo Chicken Plucker is an easy to use feather removing machine, suitable for use with birds such as chicken, turkey and duck. The electrical appliance consists of a stainless steel drum lined with yellow rubber fingers and as the base of the drum spins around these rub against the poultry removing the birds' feathers quickly and efficiently. With an easy to use on/off switch this plucker can process between five and six birds including chicken, duck, goose or turkey and takes just 15-30 seconds to de-feather one bird. The included water pipe rinses the inside of the barrel to drain away the removed feathers; this will ensure the appliance continues to work at its optimum efficiency level.

This essential time saving device is ideal for use in the farming industry or in an abattoir business.

Item Contents

The KuKoo Poultry Plucking Machine includes a stainless steel barrel with a diameter of 50cm, 106 rubber fingers, built in water pipe and power cable with 13A 3 pin plug.

Technical Information

Voltage: 220V/50hz Power Output: 1.5kW

Motor: 2HP Weight: 65kg

Product Specifics


Dimensions: 56cm width x 56cm depth x 86cm height

Capacity: Holds between 5 and 6 medium to large sized poultry.

Specification

Product Features

- 1) Waste drain chute: Here is where the water and feathers will be drained out of the machine.
- 2) Rubber fingers: These rub against the bird to remove the feathers, we also sell replacements should they break off after excessive use.
- 3) Stainless steel barrel: Insert the birds into here when the machine is turned on, be sure to turn the machine off before removing the birds.
- 4) Water pipe: Here is where to connect a hose pipe or other water supply.
- 5) ON/OFF switch
- 6) **Spinning disc**: This moves the birds around the machine to make sure all parts of the birds come into contact with the rubber fingers.



Monster Guarantee

On purchasing this product from our Monster Chef range you qualify for our 12 month electrical item guarantee. This does not cover the rubber fingers.

User Guide

Operation Instructions

- 1) Ensure the power switch is in the OFF position and the appliance is situated on a flat and even surface.
- 2) Check the adapter and cable to ensure they are in good condition and they comply with the output voltage required.
- 3) Using water near electrical appliances can be dangerous, be sure to connect an RCD between the machine and the power supply. This will instantly cut off the electricity supply to the machine to prevent potentially fatal shocks.
- 4) Turn on the power source and turn the power switch to the ON position. Check the rotating disc at the bottom of the barrel is running smoothly without any blockages. If there is anything blocking the disc, make sure to turn off the power before removing it.
- 5) Attach your hose pipe and water supply to the water pipe situated on the outside of the barrel.
- 6) After slaughter scald the poultry in hot water for five to six minutes, this will soften the feathers so they can be removed faster.
- 7) Turn on the appliance and put the poultry into the barrel. After 10 seconds turn on the hose, which should wash away removed feathers from the bird and any that have gathered around the edge of the barrel.
- 8) Multiple poultry can be added to the machine and this model can defeather 5-6 birds at a time. This will increase the build up of feathers around the edge of the machine so constant hosing will be required in order to ensure it works efficiently and removed feathers are drained away from the birds.
- 9) Removed feathers and water are drained away from the barrel via the waste drain chute
- 10) Turn off the machine before retrieving any poultry from the barrel. There may be a few feathers that require hand plucking. The machine should be cleaned and disinfected after every use.

Troubleshooting

Resolution Guide

Please read through the guide below if you have any issues or faults with your poultry plucker. The information covers and resolves the majority of frequently asked questions.

Q: The rotating disc is not working.

A: If the power is on and the disc at the bottom of the barrel stops spinning, turn off the power and check inside the barrel for any excess feathers or broken rubber fingers. If the issue continues contact our Support department using the details provided on the contact page.

Q: The rotating disc has become slow.

A: If the rotating disc has started spinning at a slower speed, turn off the power switch and remove the cable from the power source. Reach underneath the machine or carefully tilt it onto its side. Locate the motor that attaches the drive belt to the three spoke wheel. Above the motor you will see 4 bolts that hold the motor in place, loosening these bolts will allow the motor to move from side to side to act as a belt tensioner and tighten the drive belt. Remember to secure the bolts in place after adjusting. If the issue continues contact our Support department using the details provided on the contact page.

Q: The rubber fingers are worn and no longer remove feathers.

A: After a while the rubber fingers can wear away and will stop working as efficiently. Replacements can be purchased through out Sales department, using the details provided on the contact page.

Q: The feathers are not being plucked from the bird.

A: Ensure you have soaked the bird in hot water for at least 5 minutes, birds with thicker feathers may require longer or hotter water. Then make sure you have the correct machine for the type of poultry you are plucking. The CPK50 should only be used with poultry such as duck, chicken, goose, turkey and a maximum of five to six birds at a time. Any smaller birds can be placed in the CPK30 plucking machine. If the issue continues contact our Support department using the details provided on the contact page.

Safety Advice

Safe Working Practice

Please read through the safe working practice to ensure prevention of injury or damage to the device.

Do not operate the device in areas of high temperature or humidity as the machine may not function correctly.

Do not use the machine if the adaptor wire is frayed or damaged.

When the device is not in use ensure that the power plug is removed from the socket. This will prevent damage to the appliance through power surges.

This appliance can be dangerous if the power cord or wires come into contact with water. Attaching a RCD adaptor will instantly cut off the electricity supply to the machine to prevent potentially fatal shocks.

Clean this product after every use and unplug the appliance from the wall whilst cleaning.

Please do not insert animals or objects other than poultry into the machine. This can result in damage to the rubber fingers and spinning disc which will affect the working order of the appliance.

Please do not insert any live poultry into the machine, animal cruelty is a criminal offence.

Only use this appliance with whole and intact poultry to avoid damage and bruising to the flesh of the bird.

This machine can only hold between seven and eight birds, overfilling the barrel can cause damage to the machine and prevent it from working correctly. This capacity is dependent upon the size of the poultry, as different breeds of bird may be smaller or larger than average.



Contact Us

Sales Department

For information regarding this device or other products from our Monster divisions please use the following details below.

Tel: 01347 878888

Email: hello@monstershop.co.uk

Support Department

For queries about this device, warranty, returns or reporting faults please use the following details below.

Tel: 01347 878887

Email: help@monstershop.co.uk

Website

To view our product range and fantastic offers in the Monster divisions please visit our website

www.monstershop.co.uk

Address

To visit our office Monster House and view our products, send postal correspondence or return items our address is provided below.

Monster House, Alan Farnaby Way, Sheriff Hutton Industrial Estate, Sheriff Hutton, York YO60 6PG



Monster Group (UK) is one of the UK's fastest growing online retailers. We supply a diverse range of products which offer exceptional value for money. We strive to provide the best possible customer experience with free UK delivery across all our products and a Monster Guarantee for 100% satisfaction.

Our dedicated customer service team will be more than happy to help with any questions you may have.

Home & Garden
Storage Shelving
Sign & Digital
Retail & Hospitality
Commercial Equipment

Check out all our Monster brands at www.monstershop.co.uk