



10281

Coin Counting Machine

T-MECH

Try **Monster** - Buy **Monster** - Be **Monster**

Specification

Product Description

The T-Mech electronic coin counting machine can take up to 500 mixed coins at once. The machine feeds the coins through evenly without jamming, and sorts them at an incredible speed of 270 coins per minute, saving you time and therefore money (because time IS money).

It works completely unsupervised, so you can just load it up and get on with other things, and when you return you know you'll have a load of accurately sorted and counted coins waiting for you. As if this weren't enough, the T-Mech electronic coin counting machine also has a batch function for each denomination, so all you need to do is fill it up, select the right function, bag up the coins at the end, and then deliver them to the bank.

User-friendly, with a clear 4-digit LED display, the coin counting machine is as easy to navigate as it is to transport. Built to last, but light enough to carry, it can be taken anywhere you need to count coins in a hurry- shops, schools, pubs, clubs, restaurants, arcades, bookmakers and casinos, to name just a few.

Item Contents

T-Mech Coin Sorter
Built-In 3 Pin Plug
8 Coin Drawers

Specification

Technical Information

Voltage:	220 Volts
Power Output:	45 Watts
Counting Speed:	270 Coins per Minute Max
Display Range:	1- 999
Currency:	Great British Pounds

Product Specifics

Dimensions:	345 x 306 x 260 mm
Weight:	3.9 Kg

Monster Guarantee

If you wish to return a product in perfect working order, we provide a 14 day returns policy as long as the item is unopened and in a resalable condition. A 12 month warranty applies to all of our electrical products; we will cover labour, parts and delivery charges. Our policy is to try and fix the item before arranging an exchange or refund. If for any reason a part is missing please get in touch with us within 7 days on receipt of your order. You can call or email our friendly and helpful Customer Support Team. For full terms and conditions contact our Support Department via the details on the Contact Us page.

Specification

Product Features

- 1) Power Switch (Behind)
- 2) Coin Channel
- 3) Hopper
- 4) Display
- 5) Control Unit
- 6) Coin Drawer



User Guide

Operation Instructions

Count Function

1. Set the coin sorter on to an even surface so that the coins can be accurately processed through the hopper and into each coin channel.
2. Set the batch amounts for each channel. Each channel can have a set batch between 0-999 so that a maximum amount of coins can be processed through each one. This is necessary for bagging when cashing in change.

To set the batch amount press the 'SET' button to select the channel. Then press the 'BAT' button and using the '-' & '+' buttons adjust the amount that you wish to batch.

If a channel is set to '0' the coin counter will keep processing coins through even if the coin drawer is full, unless the 'Start/Stop' button is pressed or there are no coins fed through within 20 seconds.

By holding the '-' button for 7 seconds all channel will be set back to '0'. The channel setting are also memorised once the coin sorter has been switched off, so it is not necessary to set batch amounts for every use.

3. To operate the coin sorter, fill the hopper with the coins that you wish to count and press the 'Start/Stop' button. This will start to feed through the coins into the coin drawers and will stop when the hopper is empty or by pressing the 'Start/Stop' button again.
4. To check the amount in each coin drawer wait until the coin counter has finished processing the coins and press the 'Report' button. By pressing the 'Report' button you can cycle through each channel to show how many coins have been counted into each coin drawer. To exit the report function, press the 'C' button.
5. If a foreign body falls into the sorter and gets processed through, it will fall into a compartment at the back of the unit. Open the back case to retrieve the rejected item.
6. If a channel does appear to be jammed, this can be released by pressing a finger into one of the channels and pushing up until the blockage becomes free.

Troubleshooting

Resolution Guide

Please read through the guide below if you have any issues or faults with your device. The information covers and resolves the majority of frequently asked questions.

Q: The display is showing error message 'EA'.

A: If the error message 'EA' is showing on the screen it means that the optical sensor inside the coin counter is blocked. Remove the back casing of the coin sorter by unscrewing the three holding bolts at the bottom of the case. This will allow access to the carry tray which can be spun around by hand. Move the tray around until the glass optical sensor is in front of you. Check the sensor for dust and clean with a damp cloth. Do not use liquid or aerosol cleaners. If there is dust on the optical sensor it will prevent the coin sorter from working properly. If the display is regularly showing error message 'EA' then the environment the coin sorter is kept in may be too dusty for it to function properly. Re-locate or protect the coin sorter from the dusty environment.

Q: The display is showing error message 'E1' – 'E8'.

A: If the error message 'E1' – 'E8' appears in the display, it means that the counting sensor of the relevant channel is blocked and it cannot process the coins through. To unblock the channel push a finger into the blocked channel to release the coin causing the blockage. The error message will disappear and normal function can resume.

Q: The display is showing error message 'E09'.

A: If error message 'E09' is showing on the screen it means that the running sensor is blocked. Ensure that the sensor is free from coins or dust as this may be blocking the sensor from working properly.

If any of the following issues keep persisting, there may be an internal fault with the machine. Please contact our Customer Support team to resolve any issues.

Safety Advice

Safe Working Practice

Please read through the safe working practice to ensure prevention of injury or damage to the device.

Do not operate the device in areas of high temperature or humidity as the machine may not function correctly.

Do not use the machine if the adaptor wire is frayed or damaged.

When the device is not in use, ensure that the power plug is removed from the socket. This will prevent damage to the appliance through power surges.

This appliance can be dangerous if the power cord or wires come into contact with water. Attaching a RCD adaptor will instantly cut off the electricity supply to the machine to prevent potentially fatal shocks.

Never operate the machine under strong light.

Unplug the unit from the wall whilst cleaning. Use a damp cloth or the brush provided to clean. Avoid using liquids or aerosol cleaners.

Please do not reach into the loader or put your hands inside the machine as it could cause injury.

Please exercise caution when loading the money into the hopper. The counting machine processes the coins very quickly when the counting sensor is activated.

Do not attempt to process any other item through the coin sorter as this can cause damage to the machine.



Contact Us

Sales Department

For information regarding this device or other products from our Monster divisions please use the following details below.

Tel: 01347 878888

Email: hello@monstershop.co.uk

Support Department

For queries about this device, warranty, returns or reporting faults please use the following details below.

Tel: 01347 878887

Email: help@monstershop.co.uk

Website

To view our product range and fantastic offers in the Monster divisions please visit our website

www.monstershop.co.uk

Address

To visit our office Monster House and view our products, send postal correspondence or return items our address is provided below.

Monster House, Alan Farnaby Way, Sheriff Hutton
Industrial Estate, Sheriff Hutton, York YO60 6PG



Monster Group (UK) is one of the UK's fastest growing online retailers. We supply a diverse range of products which offer exceptional value for money. We strive to provide the best possible customer experience with free UK delivery across all our products and a Monster Guarantee for 100% satisfaction.

Our dedicated customer service team will be more than happy to help with any questions you may have.

Home & Garden
Storage Shelving
Sign & Digital
Retail & Hospitality
Commercial Equipment

Check out all our Monster brands at www.monstershop.co.uk
