



Spray flower mouth



Filing hopper

READY DMX FAULT HEAT



MENU UP DOWN ENTER

Cold fireworks spark machine		Warning ! The ejected spot cannot touch any object in the air. It is forbidden to block and cover the outlet of the fame machine. When the flame is sprayed, please close the cover of the added material. Don' t block the air inlet and the air outlet to impact on teat dissipa-tion. caveat! Prohibit non-professionals from opening it repair. There is electricity in the machine and the touch may cause electric shock. People and flammable materials keep a safe distance of more than 3meters.wait a few seconds. each time the fame exceeds 30 seconds will affectthe life of the machine
50~60Hz	Max connections: 6pcs	
500W 3.0A	Fuse: 10A	
N.W.: 5.5kg	Dimensions:200x186x260mm	

OFF ON

DMX IN

DMX OUT

FUSE

POWER IN

POWER OUT