



T-Mech Swing Gate Opener Wireless Keypad

210347

INSTRUCTION MANUAL

www.monstershop.co.uk



SPECIFICATION

PRODUCT DESCRIPTION

Secure access control is an essential component of any automatic gate system, whether it's for your home or business.


This Wireless keypad is the perfect accessory for our Swing Gate Opener. Easy to install and set-up, you'll be up and running before you know it!

USER GUIDE

INITIAL SET-UP

1. Insert 4 AAA batteries into rear of the keypad.
2. Attach keypad cover.
3. Press 0000* on keypad to enter programming mode.
4. Press 59* on keypad to start programming.
5. To program 1st channel press 01# on keypad.
6. Then press control board learning button (see Diagram 1).
7. Press 1111# on keypad within 5 seconds to control single leaf gate.
8. Channel One factory set default code is 1111.
9. Press 02# to program second channel.
10. Then press control board learning button.
11. Then press 2222#.
12. Second channel default code is 2222.
13. The Keypad is now connected to the Gate Opener

Diagram 1



Control Board
Learning Button

MODIFY INSTALLATION CODE AND PIN CODE

INSTALLATION CODE.

The factory set default code is 0000. You can change this by following the instructions below.

1. Press 0000* on the keypad to enter the programming mode.
2. Press 69# on the keypad.
3. Now enter your new four-digit code followed by # e.g. 1234#.
4. The installation code has now been changed.

PIN CODE.

1. Press 0000* on the keypad to enter the programming mode.
2. Press 01# (or 02# for Channel 2) on the keypad to modify the channel 1 PIN code.
3. Now enter your new four-digit PIN code followed by # e.g. 1234#.
4. Repeat the process to modify the PIN code for channel 2.

SAFETY ADVICE

SAFE WORKING PRACTICE

Please read through the Safe Working Practice to ensure prevention of injury or damage to the device.

- Do not use this product for anything other than its intended purposes.
- Ensure you have read and fully understood the instruction manual and safety advice before using this product.
- Do not allow children to use this product.
- Do not allow children to play with the opening controls or the remote controls.
- Do not immerse the product in water.
- Do not touch the electrical components of this product.
- Do not attempt to repair the product yourself, repairs should be carried out by a qualified technician.
- Do not clean this product with flammable liquids.

Monster Group UK Limited's liability will be limited to the commercial value of the product only.

Monster Group (UK) is one of the UK's fastest growing online retailers. We supply a diverse range of products which offer exceptional value for money. We strive to provide the best possible customer experience with free UK delivery across all our products and a Monster Guarantee for 100% satisfaction.

For information regarding this device or other products from our Monster divisions please contact Sales.

SALES

TEL: 01347 878 888

EMAIL: hello@monstershop.co.uk

For queries about this device, warranty, returns or reporting faults please contact Support.

SUPPORT

TEL: 01347 878 887

EMAIL: help@monstershop.co.uk

Pour plus d'informations concernant cet appareil ou d'autres produits de nos divisions de Monster veuillez utiliser les détails suivants ci-dessous.

DÉPARTEMENT COMMERCIAL

TEL: 01347 878 888

EMAIL: bonjour@monstershop.eu

Pour les interrogations concernant cet appareil, la garantie, les retours ou les défauts de déclaration veuillez utiliser les détails suivants ci-dessous.

DÉPARTEMENT DE SOUTIEN

TEL: 01347 878 887

EMAIL: help@monstershop.co.uk

Para información sobre este dispositivo u otros productos de nuestras divisiones de Monster por favor use los siguientes detalles.

DEPARTAMENTO DE VENTAS

TEL: 01347 878 888

EMAIL: hola@monstershop.eu

Para consultas sobre este dispositivo, la garantía, devoluciones o denuncias de fallos por favor use los siguientes detalles.

DEPARTAMENTO DE SOPORTE

TEL: 01347 878 887

EMAIL: help@monstershop.co.uk

Für Informationen bezüglich dieses Geräts oder anderer Produkte aus unserer Monster-Abteilung, benutzen sie die folgenden unten aufgeführten Angaben.

VERKAUFSABTEILUNG

TEL: 01347 878 888

EMAIL: hallo@monstershop.eu

Für Fragen über dieses Gerät, die Garantie, Rückgaben oder bei Störungen, benutzen sie die folgenden unten aufgeführten Angaben.

SUPPORT-ABTEILUNG

TEL: 01347 878 887

EMAIL: help@monstershop.co.uk

Per informazioni riguardanti questo dispositivo o altri prodotti dalle categorie Monster utilizzare i dettagli sotto riportati.

DIPARTIMENTO VENDITE

TEL: 01347 878 888

EMAIL: ciao@monstershop.eu

Per domande riguardo dispositivo, garanzia, reso o per riferire di guasti, utilizzare i dettagli sotto riportati.

DIPARTIMENTO SUPPORTO

TEL: 01347 878 887

EMAIL: help@monstershop.co.uk

Monster House, Alan Farnaby Way,
Sheriff Hutton Industrial Estate,
Sheriff Hutton, York, YO60 6PG
www.monstershop.co.uk



 Try **Monster**. Buy **Monster**. Be **Monster**. 