

SAFETY PRECAUTIONS

The water heater must be well ventilated

- The use of gas must be consistent with the type of gas indicated below.
- When using water heater, must maintain indoor air circulation. after use must close air source to prevent air leakage.
- Water from the water heater is not drinkable
- Water heater must be installed in a well ventilated place, install smoke pipes, and according to the specifications must be maintain indoor air circulation. do not install flue or ventilation can cause life-threatening

TECHNICAL PARAMETERS

The product name	Portable Horse Shower 18L	
Product mode	212157	
Using gas	LPG(20Y) <input checked="" type="checkbox"/>	NG(12T) <input type="checkbox"/>
The rated pressure	2800pa	2000pa
Apply pressure	0.025~0.8MPa	
Rated heat load	36KW	
Hydnathemal lapadty	Temperature rise25kwhen1 kg/min	
Enation standard	S09001-2003	