



**23293**

# Electric Curing Oven- Re-attaching the Fan



Try **Monster** - Buy **Monster** - Be **Monster**


# User Guide

## Assembly Instructions

1. Remove the fan cover from the top of the fan.
2. Remove the bolt and washer from the bottom of the shaft.



3. Using the 4 bolts in the top of the oven, bolt the fan down. You will need a 12/14mm spanner.
4. Line up the impeller and shaft of the fan.
5. Use a tool such as a socket to push the impeller onto the shaft.
6. Use a socket to insert the washer and bolt on to the bottom of the shaft through the hole in the oven's top plate.




A look at the hole from inside the oven.

# User Guide


## Assembly Instructions

7. When securing the bolt and washer, make sure someone is holding the top of the fan to stop it rotating. You will need a 10mm socket to tighten.
8. Tighten the bolt on the side of the impeller using a 10mm spanner. Make sure someone is holding the fan to stop it from rotating. Use the picture below to help.



Tighten  
this bolt

9. Screw the fan cover back on and make sure everything is secure.
10. Once the fan is secure. Remove the white control panel and wire it back up. Use the picture below to help. Make sure you replace the white control panel afterwards.



Brown

Earth

Blue

# Troubleshooting

## Resolution Guide

Please read through the guide below if you have any issues or faults with your device. The information covers and resolves the majority of frequently asked questions.

Q: There are parts missing from my order.

A: If there appears to be any part missing from your package contact our Customer Support team via the details on the Contact Us page within 7 days of receipt.

For all other issues please contact our Customer Support department via the details on the Contact page.

# Safety Advice

## Safe Working Practice

Please read through the safe working practice to ensure prevention of injury or damage to the device.

You will need a ladder to reach the top of the oven. Ensure that there is someone to hold the ladder steady when in use.

Be careful of any sharp edges in the top plate of the oven.

Make sure you have connected the wires correctly.



# Contact Us

## Sales Department

For information regarding this device or other products from our Monster divisions please use the following details below.

Tel: 01347 878888

Email: [hello@monstershop.co.uk](mailto:hello@monstershop.co.uk)

## Support Department

For queries about this device, warranty, returns or reporting faults please use the following details below.

Tel: 01347 878887

Email: [help@monstershop.co.uk](mailto:help@monstershop.co.uk)

## Website

To view our product range and fantastic offers in the Monster Chef division please visit our website

[www.monstershop.co.uk](http://www.monstershop.co.uk)

## Address

To visit our office Monster House and view our products, send postal correspondence or return items our address is provided below.

Monster House, Alan Farnaby Way, Sheriff Hutton  
Industrial Estate, Sheriff Hutton, York YO60 6PG



---

Monster Group (UK) is one of the UK's fastest growing online retailers. We supply a diverse range of products which offer exceptional value for money. We strive to provide the best possible customer experience with free UK delivery across all our products and a Monster Guarantee for 100% satisfaction.

Our dedicated customer service team will be more than happy to help with any questions you may have.

Home & Garden  
Storage Shelving  
Sign & Digital  
Retail & Hospitality  
Commercial Equipment

**Check out all our Monster brands at [www.monstershop.co.uk](http://www.monstershop.co.uk)**

---