



## GLA 60/70/90 Switch Panel Replacement

- 1) Isolate the power from the cooker hood
- 2) Locate the 4 screws on top of the glass hood, unscrew each and remove the glass hood.



- 3) At the rear of the switches there are two screws holding the switch box in place. Unscrew them and lift out the box and switch panel.
- 4) While holding the box with the switches facing you, unscrew the two screws that are holding the box and switch panel together. Then separate the box from the switch panel.
- 5) Make a note of the colouring and position of the wires that are attached to the switch panel, taking a photograph is always a good visual reference.

6) Spring clips hold each wire in place. Using a very small screwdriver push down on the spring clip and pull out the wire. When all the wires are removed you can remove the old switch panel and replace with the new one.

7) To install each wire into the new switch panel be sure to refer to your note or photograph of the wires so they are placed into the correct connections. The wires should push fit into place, give each a gentle tug to make sure they are secure.

8) Fit the switch panel and the box back together and screw in the two screws.

9) Place the box and switch panel back into the cooker hood and screw in the two screws that hold them into the hood.

10) Attach the glass hood and screw in the four screws to hold the glass onto the hood. You can now test the switch panel.



If you find you are having any issues with your item please contact our Customer Support team who will be happy to help.

Phone: 01347 878887

Email: [support@monstergroupuk.co.uk](mailto:support@monstergroupuk.co.uk)