

## MAINTENANCE

- Before performing any maintenance always disconnect the gas cylinder.
- Protect this item from frost and store it indoors during winter months. Avoiding extreme cold weather conditions.
- Keep the heating item free and clear from combustible materials.
- Visually inspect burner for obstructions and keep cylinder enclosure free and clear from debris.
- Permanent damage may occur if powder or solvent comes in contact with painted or plastic components on this heating unit.
- Keep the heating unit stored away from direct sunlight.
- Before storing this unit inside, disconnect the propane gas tank from the gas valve.