
## **Beijing Silver Stone International Trade CO.,LTD.**

 TEL: 0086-10-65882880 ext. 802
 FAX: 0086-10-65882880 ext. 805

 E-mail: hannah@carpetshow.com.cn
 Website: www.carpetshow.cn

## **Instruction of Installation for Carpet Tile**

- 1. Clean the floor, plz make sure that there's no any impurity and raise dust on the floor.
- 2. Plz try to repair the high-low part to be smooth.
- 3. Glue need to be daubed evenly on the ground. Check the attached two photos





4. When the glue is damp-dry, then can start laying the carpet tile



