## **ULTRASONIC CLEANER**







- Please read instructions before use.
- Ensure power is disconnected while filling tank.
- Do not turn on without fluid.
- Minimum tank level <sup>2</sup>/<sub>3</sub>.
- Do not drop items into the tank.
- Turn off and allow fluid to cool before draining.

